



Installation Instructions for Gumleaf Colorbond Gutter Guard - For Tile Roofs



Step 1:
Clean out gutters well and flush down pipes.



Step 2:
Slide the first row of tiles back.



Step 3:
Lay gutter guard so that the chosen colour is facing up. Secure to the gutter lip with GumLeaf Screws approximately 300mm apart. Make sure to align the gutter guard nicely along the gutter lip.



Step 4:
Overlap the join of two pieces of gutter guard by approximately 10mm.



Step 5:
Interlock the join of two pieces at the back using GumLeaf screws.



Step 6:
Slide tiles back down.



Step 7:
At the corners cut the desired length of gutter guard.



Step 8:
Fold down the back piece to make a double fold to suit gutter.



Step 9:
The piece should fit comfortably into the corner.



Step 10:
Screw corner piece down.

Unit 4, 11-13 Precision Place, Mulgrave, NSW, 2756, Australia
Phone: 1300 486 532 Fax: +61 (0)2 4577 8807
International: +61 (0)2 4577 8844 info@gumleafgutterguard.com
www.diygutterguard.com.au www.gumleafgutterguard.com